

Yahi 4 & 6-Pitching Instructions



Yahi 4 pictured

In order to familiarize yourself with your new tent, we recommend you "test pitch" before embarking on your wilderness adventure. For more helpful tips, go to www.sierradesigns.com/tents.html



Package Includes: Tent Body, Rain Fly, 2 Hubbed Leg Poles and 3 ridge poles, 4 Guy Cords, 7 Ground Stakes, 1 Pole Sack with pole pocket.



Step 1: Find an even piece of ground, lay out tent body and stake corners. Assemble poles: leg poles with 2 M Hubs™ are side poles. Small diameter grey pole is center ridge, silver ridge poles are ends.



Step 2: Insert pole end ball tip of leg poles into Jake's Foot™. Push ridge poles through pole sleeves. Insert ridge pole ends of end ridge poles into leg pole M hubs™



Jake's Foot™



Leg pole with M Hub™



Center ridge pole grommet and clip attachment



Jake's Foot™ with fly clip



Step 3: Attach tent body to poles using Twist Clips™. Insert ends of center ridge pole in grommets and clip to pole



Step 4: Drape rain fly over tent body. Attach rain fly to Jake's Foot™ using clip on fly. Stake out tent vestibules and guy out as needed.